



Zenith Upholstery Care & Cleaning ***Non-Leather Upholstery***

To prevent buildup of dirt and contaminants, which may cause permanent staining, periodic cleaning is highly suggested. The frequency of cleaning is dependent upon the environmental conditions the material is subjected to. In general, most common stains can be cleaned using warm, soapy water and clear water rinses.

For more stubborn stains, use Formula 409® commercially available cleaner in accordance with the manufacturer's instructions. **DO NOT use Full strength rubbing alcohol or mineral spirits as these products can severely damage or discolor the vinyl.**

We recommend repeated rinsing with clear water after any cleaning procedure.

Bleach cleanable: When disinfecting with bleach, dilute with water up to a 9:1 ratio (10%). Liberally apply diluted disinfectant using a sponge. Rinse with cold water several times. Wipe Dry and repeat if necessary. Federal regulations require that guidelines on the bleach label to be followed for antiseptic or antimicrobial purposes.

The following disinfectant cleaners are approved for use:

- Asepticare TB II
- Lysol Foaming
- Birex
- Precise (Caltech)
- Cavicide (Metyrex)
- Super Sani-Cloth PDI
- Citrace (Caltech)
- Virex 256
- Dispatch
- Wex-cide
- CaviWipes
- Virox 5
- Oxivir TB and Oxivir Plus.

Follow the manufacturer's directions very carefully and use personal protective equipment, as required, and ensure cleaning takes place in a well-ventilated area.